



Electrolux

Instruction Book

使用說明手冊

사용 설명서

Sách Hướng Dẫn

Buku Petunjuk


คู่มือการใช้งาน














كتيب التعليمات

600 CORDLESS CLEANER

EFP61712A / EFP61713A / EFP61712 /

EFP61714 / EFP61713





*

Available in specific models only.

只適用於指定型號

특정 모델에만 해당 됩니다.

Chỉ có ở một số kiểu máy nhất định.

Tersedia hanya pada model tertentu.

มีเฉพาะบางรุ่นเท่านั้น







متوفر في نماذج محددة فقط











Carpet










Hard Floor






















ANZ	KSD-18W-265060HA
SG/ MY/HK/ MENCA (UAE)	KSD-18W-265060HK
KRH	KSD-18W-265060HO
THE/VNE/IDH	KSD-18W-265060HT
TWH	KSD-18W-265060HU













 www.shop.electrolux.com



ESKW6	ZE195	ZE189	EPPCS2	ZE187	ZE158	ZE159
900 923 742	900 923 813	900 923 803	900 923 550	900 923 769	900 923 440	900 923 442
Yearly Performance Kit	Extra Battery 2.5Ah/54Wh	Extra Battery Taiwan / Japan 2.5Ah/54Wh	PowerPro Cleaning Station	PowerPro Mop Nozzle	Standard Pads	Delicate Pads

*Accessories are subject to country availability.

A27940403