



Electrolux

Instruction Book

使用說明手冊

사용 설명서


Sách Hướng Dẫn

Buku Petunjuk






คู่มือการใช้งาน




کتاب التعليمات


700 CORDLESS CLEANER











*Actual product may differ from illustration.



































www.shop.electrolux.com




ESKW7

900 923 814
Performance Kit




ZE155

900 923 379
PetPro+




ZE149

900 923 380
BedProPower+



ZE149A

900 923 381
BedProPowerUV+



ZE156

900 923 369
**PowerPro
Hard Floor Nozzle**




ZE196

900 923 816
Extra Battery




KIT23

900 923 383
Home and Car Kit




KIT22

900 923 354
Duster Kit




ZE177

900 923 744
PowerProMop+ Nozzle




EPPCS2

900 923 726
Cleaning Station



ZE158

900 923 440
Standard Pads



E206S

900 168 460
**S-bag® Hygiene Anti-Allergy
for Emptying Station**



E203S

900 168 459
**S-bag® Anti-Odour
for Emptying Station**

*Accessories may vary by market.

